



YES 600 Thermal Clip Storefront System

Installation Manual

©2018 YKK AP America Inc. is a subsidiary of **W**YKK Corporation of America.



TABLE OF CONTENTS

Installation Notes	Page ii
Frame Types	Page iii to iv

PARTS DESCRIPTION

Framing Members	Page 1 to 2
Door Framing Members	Page 3
Accessories	Page 4 to 5

FRAME FABRICATION

Determine Frame Size	Page 6
Fabricate Sill Flashing	Page 7
Fabricate Two Piece Verticals for Screw Spline Assembly	Page 8
Fabricate Tubular Verticals for Shear Block Assembly	Page 9
Fabricate Head and Sill Members	Page 10 & 11
Fabricate Intermediate Horizontal Members	Page 12
Fabricate Glazing Adaptors	Page 12
Fabricate Face Covers	Page 13

FRAME ASSEMBLY

Install Mullion End Caps	Page	14
Install End Dams	Page	14
Assemble Vertical Through Frames	Page	15
Assemble Continuous Head & Sill Frames	Page	16

FRAME INSTALLATION

Install Sill Flashing	Page 1	17
Install Frames	Page 1	18
Install Mullion Anchors	Page 1	19
Seal Door Jamb to Sill Flashing	Page 2	20
Apply Internal Sealant	Page 2	20
Install Joint Plugs & Water Deflectors	Page 2	21
Apply Perimeter Sealant	Page 2	22
Install Glazing Adaptors	Page 2	22

GLAZING

Glazing Standard Frames	Page 23 & 24
Glazing Structural Silicone Glazed Frames	Page 25 to 27



Installation Notes

1. Do not drop, roll or drag boxes of aluminum framing. Move and stack boxes with proper support to prevent distortion. If fork lifts are used be especially careful about striking the boxes when lifting or moving.

2. Store in a dry, out of the way area. If rain exposure, condensation or any water contact is likely, then all packaging material should be removed. Wet packaging materials will discolor and may stain aluminum finishes and paints.

3. All materials should be checked for quality and quantity upon receipt, YKK AP must be notified immediately of any discrepancies in shipment. Check to make sure that you have the required shims, sealants, supplies and tools necessary for the installation.

4. Carefully check the openings and surrounding conditions that will receive your material. Remember, if the construction is not per the construction documents, it is your responsibility to notify the general contractor in writing. Any discrepancies must be brought to the general contractor's attention before you proceed with the installation.

5. Gather your shop drawings, materials, packing list, and this installation manual. Carefully review parts location, the sequence it goes therein, when you glaze it and how you seal it. Installation instructions are of a general nature and may not cover every condition you will encounter. The shop drawings and/or installation manuals were prepared specifically for the product.

6. Any material substitutions must be of equal or greater quality.

7. Make certain that material samples have been sent for compatibility testing for all manufacturer's sealants involved. Make certain sealants have been installed in strict accordance with the manufacturer's recommendations and specifications.

8. Remember to isolate, in an approved manner, all aluminum from uncured masonry or other incompatible materials.

9. System-to-structure fasteners are not supplied by YKK AP. Fasteners called out on shop drawings are to indicate minimum sizes for design loading.

10. Entrances are to be installed plumb, square, level and true.

11. If any questions arise concerning YKK AP products or their installation, contact YKK AP for clarification before proceeding.

12. YKK AP storefront and/or curtain wall framing is typically completed before drywall, flooring and other products which may still be in process. Wrap and protect the material when stored at the job site.

13. Cutting tolerances are plus zero (0"), minus one thirty second (-1/32") unless otherwise noted.

14. Check our website, www.ykkap.com, for the latest installation manual update prior to commencing work.

ap[®]

FRAME TYPES

SCREW SPLINE

-Verticals are cut to the full height of the frame. -Horizontal members are cut in between the verticals mullions.

- -Intermediate verticals consist of two separate pieces thus permitting sections of framing to be assembled and then snapped together.
- -Intermediate horizontals are joined to verticals by screw spline attachment thus eliminating the requirement for shear blocks.

-Expansion verticals, placed approximately every twelve to fifteen feet, allow for long continuous runs of YES 600 framing.



SHEAR BLOCK

-Verticals are cut to the the height of the frame. -Horizontal members are cut in between the verticals mullions.

-Intermediate verticals are one piece members that are anchored to the structure with mullion end anchors.

-Head and sill members are attached to the mullion end anchors.

-Intermediate horizontals are attached to the verticals with shear blocks.





FRAME TYPES

CONTINUOUS HEAD AND SILL

-Head and sill members may run the full width of the frame opening for openings 24'-0" or smaller. -Intermediate verticals are cut to the day light

- opening between the head and sill members.
- -Fasteners are run through the head and sill into the screw splines of the one piece intermediate verticals.
- -Intermediate horizontals are attached to verticals with shear blocks.
- **Note:** Sill flashing is not required with continuous head and sill frames.



-Vertical structural silicone glazing is available for the YES 600 Storefront Framing System.
-System description and fabrication is the same as for the continuous head and sill frame type described above.

GENERAL NOTES:

-A qualified person must review shop drawings for system application and anchor sizing and spacing.



FRAMING MEMBERS

	Horizontal 1-3/4" x 4-1/2"	E9-1801		Horizontal 1-3/4" x 6"	E9-1811
	Tubular Vertical 1-3/4" x 4-1/2"	E9-1803		Tubular Vertical 1-3/4" x 6"	E9-1813
٦ ۴	Two Piece Vertical 1-3/4" x 4-1/2"	E9-1804		Two Piece Vertical 1-3/4" x 6"	E9-1814
	Flat Filler Use with E9-1804	E9-1805		Flat Filler Use with E9-1814	E9-1038
L ĥ	Expansion Mullion 1-3/4" x 4-1/2" Female Weathering Gasket E2-0065 Not Included	E9-1806		Expansion Mullion 1-3/4" x 6" Female Weathering Gasket E2-0065 Not Included	E9-1816
	Expansion Mullion 1-3/4" x 4-1/2" Male Use with E9-1806	E9-1807		Expansion Mullion 1-3/4" x 6" Male Use with E9-1816	E9-1817
S S	SSG Vertical 1-3/4" x 4-1/2"	E9-1808		SSG Vertical 1-3/4" x 6"	E9-1818
E	SSG Expansion Mullion 1-3/4" x 4-1/2" Use with Self Weathering Gasket E2-0065 Not Included	E9-1824		SSG Expansion Mullion 1-3/4" x 6" Use with Self Weathering Gasket E2-0065 Not Included	E9-1825
	Head/Sill/Jamb 1-3/4" x 4-1/2"	E9-1821	3	Head/Sill/Jamb 1-3/4" x 6"	E9-1822
	Sill Flashing For 4-1/2" Deep System	E9-1848]	Sill Flashing For 6" Deep System	E9-1849



FRAMING MEMBERS

Glazing Adaptor For 1/4" Glazing	E9-1809	Face Cover 5/8" x 1-3/4"	E9-1851
SSG Glazing Adaptor For 1/4" Glazing	E9-1810	Face Cover 1-5/8" x 1-3/4"	E9-1852
Pocket Filler	E9-1823	Face Cover 2-1/8" x 1-3/4"	E9-1853

DOOR FRAMING MEMBERS

V	Single Acting Door Jamb 1-3/4" x 4-1/2" E2-0051 Included	AS-0479		Single Acting Door Jamb 1-3/4" x 6" E2-0051 Included	AS-0471
	Single Acting Transom Bar for Offset Glazing 1-3/4" x 4-1/2" E2-0051 Included	AS-0477		Single Acting Transom Bar for Offset Glazing 1-3/4" x 6" E2-0051 Included	AS-0472
at	Single Acting Transom Bar for Center Glazing 1-3/4" x 4-1/2" E2-0051 Included	AS-0402		Double Acting Door Jamb 1-3/4" x 6"	E9-0473
	Double Acting Door Jamb 1-3/4" x 4-1/2"	E9-0480		Double Acting Transom Bar for Offset Glazing 1-3/4" x 6" E2-0062 Included	AS-0474
	Double Acting Transom Bar for Offset Glazing 1-3/4" x 4-1/2" E2-0062 Included	AS-0478	ן ב	Door Jamb Glazing Pocket Filler For 1" Glazing, Use with AS-0471 & E9-0473	E9-1891
چ ا	Door Jamb Glazing Pocket Filler For 1" Glazing, Use with AS-0479 & E9-0480	E9-1889	۲ ۵	Door Jamb Glazing Pocket Filler For 1/4" Glazing, Use with AS-0471 & E9-0473	E9-1892
ار م	Door Jamb Glazing Pocket Filler For 1/4" Glazing, Use with AS-0479 & E9-0480	E9-1890		Door Stop Assembly E9-0409 & E9-1113 (mill) Elastomer Weathering E2-0051 Included	AS-0401
	Intermediate Door Jamb 1-3/4" x 4-1/2" Use with AS-0401	E9-0410	لیا م	Transom Glazing Pocket For 1/4" Glazing	E9-0434
<u>[]</u>	Sash Base Use with E9-0403 & E9-0413 Glass Stops	E9-0408		Transom Glazing Pocket For 1" Glazing	E9-0435
[]	Transom Glass Stop For 1/4" Glazing	E9-0403		Threshold 1/2" x 4"	E9-0407
<u>لا</u>	Transom Glass Stop For 1" Glazing	E9-0413			



ACCESSORIES

	Shear Block For 4-1/2" Deep System Use (2) HM-1012 & (2) FC-1012, Not Included	E1-1030		End Dam For Sill Flashing E9-1849	E1-1188
	Shear Block For 6" Deep System Use (2) HM-1012 & (2) FC-1012, Not Included	E1-1031		Setting Block For 1/4" Glazing at Transom Head	E2-0019
	Mullion "J" Anchor For 4-1/2" Deep System Use (2) HM-1012 & (1) FC-1012, Not Included	E1-1035		Setting Block For 1" Glazing at Transom Head	E2-0056
	Mullion "J" Anchor For 6" Deep System Use (2) HM-1012 & (1) FC-1012, Not Included	E1-1036		Setting Block For 1/4" & 1" Glazing at Intermediate Horizontal	E2-0202
	SSG Water Deflector For Ends of Horizontals at SSG Verticals	E1-1032		Setting Block For 1/4" & 1" Glazing at Sill	E2-0253
	Temporary Glass Retainer For Structural Silicone Glazing	E1-1033		Side Block	E2-0133
5	Deglazing Tool	E1-1034		Joint Plug For Horizontal Ends	E2-0208
	Mullion End Cap	E1-1045		End Dam For Continuous Head & Sill Frame Ends	E2-0278
Sec.	Glazing Clip	E3-0015		End Dam For Continuous Head & Sill Frame Ends	E2-0276
	End Dam For Sill Flashing E9-1848	E1-1187	<u>_</u> R	Water Deflector For Neck of Horizontals	E2-0254

ACCESSORIES

<u>O</u> rs	Glazing Gasket Interior & Exterior	E2-0213	Sume	#10 x 3/8" PHSMS Type AB , Zinc Plated Steel For Attachment of E9-1809 Glazing Adaptor to Mullion	PC-1006
TE TE	SSG Glazing Spacer For Structural Silicone Glazing of Intermediate Verticals	E2-0214	Jununum	#10 x 3/4" FHSMS Type AB, Zinc Plated Steel For Attachment of Horizontal to Shear Block	FC-1012
C1	Elastomer Weathering Use with Door Frame	E2-0051	E[uuuuuu	#10-24 x 3/4" HWSMS Type AB , Zinc Plated Steel For Attachment of Shear Block & "J" Anchor to Vertical	HM-1012
2	Weathering Gasket Use with E9-1806, E9-1816, E9-1824 & E9-1825	E2-0065	Junnunum	#10 x 1" PHSMS Type AB, Zinc Plated Steel For Screw Spline Attachment	PC-1016
2:I	Glazing Gasket For Transom Glazing	E2-0052	Summunum)	#10 x 1-1/4" PHSMS Type AB, Zinc Plated Steel For Screw Spline Attachment Using E9-1821 & E9-1822	PC-1020
	Pile Weathering	E2-0062			



STEP 1 DETERMINE FRAME SIZE

Determine Frame Width:



-Measure the width of the masonry opening at the top, middle, and bottom.

-Select the smallest dimension measured and subtract 3/4" to determine the frame width. See **Detail 1**.



-Measure the height of the masonry opening several times along the entire length of opening and select the smallest dimension for the masonry opening height. See **Detail 2**.

To calculate frame height:

For Vertical Through Frames:

- -Subtract 3/4" from the masonry opening height:
 - 3/8" caulk joint at head.
 - 1/8" sill flashing.
 - 1/4" caulk joint below flashing.

- For Continuous Head & Sill Frames:
- -Subtract 3/4" from the masonry opening height: 3/8" caulk joint at head. 3/8" caulk joint below sill member
- **NOTE:** Vertical through frame widths over 24'-0" require expansion mullions every 12 to 15 feet (best location at vertical next to the door jamb.)

YES 600 must be installed with sill flashing, E9-1848 or E9-1849, for vertical through applications. Sill flashing is not required when head and sill members run continuous (frames 24'-0" or smaller).



STEP 2 FABRICATE SILL FLASHING

For Elevations without Door Framing:

-Cut sill flashing, E9-1848 or E9-1849, to the frame width determined in Step 1.

For Elevations with Door Framing:

-Cut sill flashing, from the end of the frame to the door jamb. (See approved shop drawings for this dimension)

See Detail 3.

-For openings longer than 24'-0" the sill flashing needs to be spliced every twelve to fifteen feet. -Allow for a 3/8" joint for expansion between sill flashing members.





STEP 3 FABRICATE TWO PIECE VERTICALS FOR SCREW SPLINE ASSEMBLY

-Cut the two piece vertical and jamb members to the frame height determined in Step 1.

-Mark hole locations for screw spline attachment using one of the methods below:

1. Using a short piece of each horizontal member as a template, align the glazing pockets and mark the location of each screw spline.

OR

2. Layout the hole locations as shown in **Detail 4**.

-Drill a 0.213" diameter (#3 drill bit) clearance hole at each location marked.





STEP 3 (Continued) FABRICATE TUBULAR VERTICALS FOR SHEAR BLOCK ASSEMBLY

-Cut vertical and jamb members to the frame height determined in Step 1.

-Tubular verticals require mullion anchors for the attachment head and sill members and shear blocks for the attachment of horizontal members. Mark hole locations for mullion anchor and shear block attachment using one of the methods below:

1. Using a short piece of each horizontal member with a shear block attached as a template, align the glazing pockets and mark each hole location.

OR

2. Layout hole locations for the shear blocks as shown in **Detail 5**.

-Drill a 0.161" diameter (#20 drill bit) hole at each location marked. -Attach mullion anchors and shear blocks to the mullions with (2) HM-1012 fasteners.





STEP 4 FABRICATE HEAD AND SILL MEMBERS FOR VERTICAL THROUGH FRAMES

-Cut the head and sill members to the daylight opening (D.L.O.) between verticals.

-If using vertical mullion anchors, additional fabrication to the head and sill members is required: -Mark hole locations along the "V"-groove of the head or sill 1" from each end.

-Drill a 0.213" diameter (#3 drill bit) hole at each location and countersink for a #10 fastener.



FABRICATE HEAD AND SILL MEMBERS FOR CONTINUOUS HEAD & SILL FRAMES

-Cut head and sill members to the frame width determined in Step 1.

-Continuous head and sill frames require weep holes at the sill:

-Mark the sill members, E9-1821 or E9-1822, at 1/4 points of daylight opening between vertical members along the "V"-Groove on the front leg of the sill member as shown below. -Drill 5/16" diameter weep holes at each location marked through both the front and center

leg of the sill member.

See Detail 7.





STEP 4 (Continued) FABRICATE HEAD AND SILL MEMBERS FOR CONTINUOUS HEAD & SILL FRAMES

Fabricate holes in the head and sill members for the attachment of vertical members:

-Mark the centerlines of each intermediate vertical across the back of the head or sill. -Using short pieces of vertical members as a template, center the template along the vertical centerlines and align the glazing pocket of the template with the head or sill. -Mark hole locations through the screw splines.

OR

-Layout hole locations on head and sill members as shown below.

-Drill 0.213" diameter (#3 drill bit) clearance holes at each location marked.

See Detail 8.





STEP 5 FABRICATE INTERMEDIATE HORIZONTAL MEMBERS

-Cut all intermediate horizontal members to the daylight opening between verticals.

Horizontal members that are attached to one piece verticals by shear blocks require additional fabrication:

-Mark hole locations at each end, 1" from the ends along the "V"-Grooves on both sides of the mullion tongue.

-Drill 0.213" dia. (#3 drill bit) holes, countersunk for a #10 fastener, at each location marked. See **Detail 9**.



<u>Detail 9</u>

STEP 6 FABRICATE 1/4" GLAZING ADAPTORS (When Required)

-Cut glazing adaptors for verticals: Cut Length = Daylight Opening plus(+) 1". -Cut glazing adaptors for horizontals: Cut Length = Daylight Opening minus(–) 1/32". -Mark hole locations 2" from each end of all adaptors along the "V"-groove. -Drill a 0.213" diameter (#3 drill bit) holes at each location marked.

See Detail 10.





STEP 7 FABRICATE FACE COVERS

For Vertical Through Frames:

-Cut vertical face covers to the same dimension as their respective vertical mullions. -Cut horizontal face covers to the daylight opening between verticals minus(–) 1/32."

For Continuous Head & Sill Frames:

-Cut vertical face covers to the daylight opening height minus(–) 1/32." -Cut head and sill face covers to the frame width determined in **Step 1**. -Cut intermediate horizontal face covers to the daylight opening between verticals minus(–) 1/32" for captured mullions.

Note: If using SSG verticals, horizontal face covers may run continuous across SSG verticals. An expansion joint, 3/8" wide, is required every 12 to 15 feet; this joint should occur at the centerline of a SSG vertical.

See approved shop drawings for horizontal face cover dimensions if using SSG verticals.



Intermediate horizontal face covers require weep holes on the bottom side of the face covers to permit water that has entered the system to properly weep out.

-Locate and mark the one third points of daylight opening (D.L.O.) along the bottom side of the face covers.

-Drill 5/16" diameter weep holes at each location marked. See **Detail 11**.

Note: Each lite of glass to have two weep holes.

FRAME ASSEMBLY

STEP 8 INSTALL MULLION END CAPS (For Vertical Through Frames Only)

-Clean the vertical mullion ends and mullion end caps with a cleaner and method approved by sealant manufacturer.

-Apply sealant to the gasket reglets and along the front of the vertical members on both ends prior to installing mullion end caps, E1-1045. -Attach mullion end caps to the vertical members

using (2) FC-1012 fastener at each end.

-Tool the excess sealant along the inside of the glazing pocket between the mullion end cap and the mullion.

-Seal all screw heads.

See Detail 12.

Note: End caps are also required for E9-1821 and E9-1822 when used as a jamb.

STEP 9 INSTALL END DAMS (For Continuous Head & Sill Frames Only)

The ends of head and sill members of continuous head & sill frames must be plugged using end dams, E2-0276 and E2-0278, at both the head and sill.

Use the following technique to install end dams at the head and sill:

-Clean the ends of the head and sill members with a cleaner and method approved by the sealant manufacturer.

-Apply sealant to all end dam surfaces that will contact the mullion.

-Insert the end dams into each end, leaving it recessed from the end of the mullion.

-Apply sealant to the end dams and tool the sealant flush with the ends of the mullion.

See Detail 13





FRAME ASSEMBLY

STEP 10 ASSEMBLE FRAMES

Vertical Through Frames:

-Clean the ends of horizontals and attachment areas of vertical members using a cleaner and method approved by sealant manufacturer.

-Apply sealant to both ends of head, horizontal, and sill members prior to assembly. -Attach head, horizontal and sill members to the two piece vertical members with (2) PC-1016 fasteners at each end.

-Using a clean cloth, wipe off the excess sealant while pushing it into the joints.

See Detail 14.

Note: If using mullion anchors, do not attach head and sill members at this time. Mullion anchors must be anchored to the structure before head and sill members are attached. See **Step 13** on **Page-19** for mullion anchor installation.





FRAME ASSEMBLY

STEP 10 ASSEMBLE FRAMES

Continuous Head & Sill Frames:

-Clean the ends of vertical members and attachment areas of head and sill members using a cleaner and method approved by sealant manufacturer.

-Apply (butter) sealant to both ends of jamb and vertical members just prior to assembly. -Attach jamb and vertical mullions to the head and sill members using:

(2) PC-1016 fasteners for 4-1/2" deep verticals.

(4) PC-1016 fasteners for 6" deep verticals.

-Apply (butter) sealant to both ends of the intermediate horizontal members and to the front, top portion of the shear block just prior to assembly.

-Attach intermediate horizontals to the shear blocks using (2) FC-1012 fasteners at each end. -Using a clean cloth, wipe off the excess sealant while pushing it into the joints.

See Detail 15.



ap[®]

FRAME INSTALLATION

STEP 11 INSTALL SILL FLASHING (Vertical Through Frames Only)

-Clean the ends of the sill flashing and end dams using a cleaner approved by sealant manufacturer. -Install E1-1187 (4-1/2" deep) or E1-1188 (6" deep) end dams at each end of the sill flashing. -Apply and tool sealant along the joint between the end dam and the sill flashing. End dams may be taped in place until the sealant cures. See **Detail 16**.

-Strike a line along the frame opening that will be the inside face of the sill flashing.

-Check the vertical masonry opening along the entire frame width and locate the smallest opening height. -Starting at the smallest opening height, install the sill flashing with 1/4" minimum shim underneath. Sill flashing must be installed level.

-Anchor the sill flashing to the structure a maximum of 6" from each end and then 18" to 24" on center. -Apply sealant to the heads of all fasteners. See **Detail 17**.



The sill flashing must be spliced every twelve to fifteen feet using 0.40" brake metal splice sleeve: -Apply bond breaker tape to center of the splice sleeve on the underside.

-Clean the splice area of the sill flashing using a cleaner approved by sealant manufacturer.

-Apply a generous amount of sealant to both sides of the sill flashing splice.

-Center the splice sleeve over the 3/8" splice joint.

-Tool the sealant up and over the edges of the splice sleeve to completely seal the joint.

-Apply and tool sealant to splice joint at the front and back of the splice sleeve.

See Detail 18.





STEP 12 INSTALL VERTICAL THROUGH FRAMES

-Immediately before installing the frames, apply a continuous bead of sealant to the back leg of the sill flashing. Make sure all surfaces are clean. -Snap frame assemblies together and set onto the sill flashing.

-Shim the head and jamb members to ensure that the frame is installed plumb, square, and true. -Anchor the frame to the structure through the

glazing pocket of the perimeter members:

- -Head and sill members: 3" on each side of all verticals and then no more than 18" on center.
- -Jamb members: 3" from each end and then no more than 18" on center.

-Seal all anchor heads.

See Detail 19.

Note: Shims must be installed at all anchor points. Anchor size and location should be determined by a qualified engineer.





INSTALL CONTINUOUS HEAD & SILL FRAMES

- Strike a line along the structure at the sill condition that will be the interior face of the frame.
 Set the assembled frame into the opening and align it with the line representing the interior face.
 Start installing the frame at the smallest opening height with a 3/8" minimum shim at the sill.
- -Shim the frame as required to ensure that it is installed level, square, and true.
- -Anchor the frame to the structure through the glazing pocket of the perimeter members:
 - -Head and sill members: 3" on each side of all verticals and then no more than 18" on center.
 -Jamb members: 3" from each end and then no more than 18" on center.

-Seal all anchor heads.

See Detail 20.

Note: Shims must be installed at all anchor points. Anchor size and location should be determined by a qualified engineer.



STEP 13 INSTALL MULLION ANCHORS (When Required)

-Bring the vertical members into place. Mullion anchors, E1-1035 or E1-1036, should already be pre-drilled for appropriate size anchor bolts.

-Match drill appropriate size holes into the structure for the anchor bolts.

-Provide anchor bolts as per job requirements. See approved shop drawings or engineering calculations for anchor bolt size and location.

-Install the anchor bolts. Make sure all verticals are installed plumb.

-Install intermediate horizontals as previously shown in Frame Assembly.

Caution: There must always be a shim under the mullion to transfer glazing dead loads to the foundation.

Head and sill members may now be attached to the vertical:

-Apply sealant to both ends of the head and sill members as previously shown in **Detail 14** on **Page-15**.

-Apply sealant to the front, top portion of the mullion anchor just prior to assembly.

-Attach head and sill members to the anchors using (1) FC-1012 fasteners at each end.

-Using a clean cloth, wipe off the excess sealant while pushing it into the joints.

See Detail 21.





STEP 14 SEAL DOOR JAMB TO SILL FLASHING

Prior to snapping the assembled frames into the door jamb, the end of the sill flashing needs to be sealed to the door jamb.

-Apply and tool sealant to all sill flashing to door jamb joints.

-Apply sealant to completely fill the door jamb cavity and ramp the sealant down onto the sill flashing.

See Detail 22.

Refer to the **20D**, **35D**, **& 50D Entrances Installation Manual** for door installation instructions.



STEP 15 APPLY INTERNAL SEALANT

-Apply a non-hardening sealant to all vertical to horizontal joints.

-Apply a non-hardening sealant to all exposed fastener heads.

-Tool the sealant to ensure a water tight seal.



STEP 16 INSTALL JOINT PLUGS AT INTERMEDIATE HORIZONTALS

Each end of the horizontal tongue must be sealed to the vertical using joint plugs, E2-0208.
Apply sealant to the three contact sides of the joint plug and install it over the tongue of the horizontal.
Tool the excess sealant up and over the joint plug to form a watertight joint.
See **Detail 24**.



STEP 17 INSTALL WATER DEFLECTORS AT SSG VERTICALS

YES 600 requires the installation of water deflector, E1-1032, to bridge the gap between intermediate horizontals at the SSG vertical.

-Clean and dry off the glazing pocket of each horizontal at the ends.

-Apply sealant to the bottom side of the water deflector on both ends as shown in **Detail 25**. -Install the water deflector centered over the opening between the two horizontals.

-Apply and tool sealant along the vertical and horizontal behind the water deflector.

-Tool the excess sealant up and over the edges of the water deflector. See **Detail 25**.

Apply Sealant Tool Sealant Up & Over Water Deflector E1-1032 Water Deflector Detail 25

STEP 18 APPLY PERIMETER SEALANT

-Install backer rod around the perimeter of the frame. -Apply perimeter sealant to the joint between the frame and the structure on the exterior and interior. See **Detail 26**.





STEP 19 INSTALL 1/4" GLAZING ADAPTORS (When Required)

-Run a bead of sealant along the gasket reglets of the members that the adaptor will attach to. Attach vertical adaptors first:

- -Center the vertical adaptor in the opening and match drill the mullion using a 0.161" diameter (#20) drill bit through the holes previously drilled in **Step 6**.
- -Attach the adaptor using a PC-1006 fastener at each end.

Attach horizontal adaptors:

- -Dry fit the horizontal adaptors between the vertical adaptors and match drill the mullion using a 0.161" diameter (#20) drill bit.
- -Remove the adaptor and apply sealant to each end of the adaptor.
- -Reattach the adaptor to the mullion using a PC-1006 fastener at each end.

-Seal all screw heads. See **Detail 27**.



STEP 18 GLAZING STANDARD FRAMES

-Cut interior vertical gaskets to Daylight Opening plus(+) 1-1/4".

-Cut interior horizontal gaskets to Daylight Opening plus(+) 3/16" for each foot of horizontal. -Apply sealant into the gasket reglets one to two inches in each direction of the corner.

-Install vertical gaskets first centered along the opening.

-Apply sealant to each end of the horizontal gasket prior to inserting into the reglet.

-Insert the gasket at each end first and then at the midpoint of the opening.

-Push the gasket into the reglet starting at the midpoint and work towards each end.

-Tool the excess sealant at the gasket corners to ensure a watertight seal.

-Cut water deflector gasket, E2-0254, to the daylight opening plus(+) 1-3/16".

-Snap the water deflector onto the bottom of the horizontal mullion tongue centered across the opening.

-Install glazing clips, E3-0015, into the mullion tongues of all framing members:

A maximum of 3" from each end and no more than 9" on center thereafter.

See Detail 28.



For Continuous Head & Sill Frames Only

-In order for the frame to weep moisture to the exterior properly, exterior glazing gaskets E2-0213 cannot run continuously along the bottom of the sill face cover.

-Mark the centerlines of weep holes along the sill face cover.

-Leave 1/2" gaps between the gasket at weep hole centerlines.



E2-0202

7/16"

7/16"

E2-0253

Daylight Opening (D.L.O.)

~



GLAZING

STEP 18 (Continued) GLAZING STANDARD FRAMES

-Determine the glass size:

	Width	Height
Standard Glazing	D.L.O. + 7/8"	D.L.O. + 7/8"

-Install setting blocks at 1/4 points or according to engineering calculations.

At intermediate horizontals: E2-0202.

At sills: E2-0253.

-Attach side blocks, E2-0133, to all jambs and captured verticals at the midpoint of the vertical daylight opening. -Carefully install glass into the frame making sure that it is properly aligned with setting and side blocks. See **Detail 30**.



<u>Detail 30</u>

E2-0213

E2-0133

Midpoint

of Opening

-Cut vertical exterior gaskets to the length of the vertical face covers.

-Cut horizontal exterior gaskets to the length of the horizontal face covers plus 3/16" for every foot of horizontal.

-Insert gaskets into the face covers.

-Using a wooden block and a rubber mallet, attach the face covers to the glazing clips. Vertical face covers must be attached first.

See Detail 31.





STEP 19 GLAZING STRUCTURAL SILICONE GLAZED (SSG) FRAMES

-Cut glazing spacer (E2-0214 for SSG mullions or Norton V-2100 glazing tape for SSG expansion mullions) to Daylight Opening plus(+) 1".

-Cut interior horizontal gaskets to Daylight Opening plus(+) 1/4" for each foot of horizontal.

-Cut interior vertical gaskets for jamb members to Daylight Opening plus(+) 1".

-Install glazing spacers or glazing tape first centered along the opening.

-Insert the horizontal gasket at each end first and then at the midpoint of the opening. -Push the gasket into the reglet starting at the midpoint and work towards each end.

See Detail 32.



A maximum of 3" from each end and no more than 9" on center thereafter. See **Detail 32**.

For Continuous Head & Sill Frames Only

-In order for the frame to weep moisture to the exterior properly, exterior glazing gaskets E2-0213 <u>cannot</u> run continuously along the bottom of the sill face cover.

-Mark the centerlines of weep holes along the sill face cover.

-Leave 1/2" gaps between the gasket at weep hole centerlines.

See **Detail 29** on Page-23.



STEP 19 (Continued) GLAZING STRUCTURAL SILICONE GLAZED (SSG) FRAMES

-Determine the glass size:

	Width	Height
Jamb to SSG	D.L.O. + 1-1/8"	D.L.O. + 7/8"
SSG to SSG	D.L.O. + 1-3/8"	D.L.O. + 7/8"

-Install setting blocks at 1/4 points or according to engineering calculations.

At intermediate horizontals: E2-0202. At sills: E2-0253.

-Attach side blocks, E2-0133, to all jambs at the midpoint of the vertical daylight opening.

-Carefully install glass into the frame making sure that it is properly aligned with setting and side blocks. See **Detail 33**.



Detail 33



Temporary glass retainers, E1-1033, must be attached to all SSG mullions:

-Attach temporary glass retainers a maximum of

2'-0" on center with #10 – 40 Tek fasteners. See **Detail 34**.

-Cut vertical exterior gaskets to the length of the vertical face covers plus(+) 1".

-Cut horizontal exterior gaskets to the length of the horizontal face covers plus 1/4" for every foot of horizontal.





STEP 19 (Continued) GLAZING STRUCTURAL SILICONE GLAZED (SSG) FRAMES

-Insert gaskets into the face covers.
-Using a wooden block and a rubber mallet, attach the face covers to the glazing clips.
See **Detail 35**.

Apply Interior Structural Silicone

-Clean all surfaces with an approved cleaner. -Apply masking tape to the mullion aligned with the edge of the glazing pocket; apply masking tape to the glass aligned with the edge of the mullion. -Apply a quality structural silicone from the bottom to the top of the joint using positive pressure to completely fill the cavity between the glass and the SSG mullion. -Using a non-scratching implement, tool the silicone immediately after running the joint.

-Exert positive pressure while tooling to ensure that the silicone completely fills the cavity; be careful not to remove too much silicone. The finished joint should be flush with the edge of the SSG mullion. See **Detail 36**.

Apply Exterior Structural Silicone Weatherseal

- -Once the interior structural silicone has cured, consult silicone manufacturer for curing time, remove the temporary glass retainers.
- -Insert an approved backer rod between the two lites.
- -Clean all surfaces with an approved cleaner and apply masking tape to both vertical edges of the glass.
- -Starting at the bottom, apply an approved silicone to the joint between the lites using positive pressure to ensure that the cavity is completely filled.
- -Using a non-scratching implement, tool the silicone immediately after running the joint.
- -Exert positive pressure while tooling to ensure that the silicone completely fills the cavity; be careful not to remove too much silicone. The finished joint should be flush with the edge of the SSG mullion.

Caution: Do not permit the silicone to skin over before tooling. Immediately remove tape after tooling the silicone.









270 Riverside Parkway Suite 100 Austell, Georgia 30168 www.ykkap.com